

NEWTON ELECTRIC BIKE CONVERSIONS

Welcome to the world of electric bikes THE 880 LED CONTROLLER

The controls on the left side of the handlebars consist of a **Red ON/OFF button**, a **Green MODE button**, a battery level indicator and a **blue 6KM/H button**.

To turn on the system: -

First, switch on the **red battery switch** on the underside of the battery, then press and hold the **Red ON/OFF button** for 2 seconds. The battery level indicator will light up showing the level of the battery.

Select the amount of assistance you want by pressing the **Green Mode button** until you reach the desired amount. Low being the minimum amount of assistance and high being the maximum amount of assistance.

The higher level of assistance used the shorter the life of the battery on your trip.

The **Blue 6KM/H button** allows you to walk alongside your bicycle at 6KM/H while you hold the button down.

To turn the system off either press and hold the **Red ON/OFF button** or turn off the **red battery switch** on the underside of the battery.

The display will turn off after 5 minutes if not used.

Each time you switch on, the assistance level will start off at the same level that you left it at when you switched the display off.